MAXX AIR™

Dual Powered

4/6/8in. High Velocity Fan

- Dual Powered - 110V AC (with included Adapter) and USB
- Compatible with Powered USB 1.0 & 2.0 Ports
- Powerful and Quiet
- All Metal Body and Blades
- Adjustable Tilt Angle
- Rocker Style Power Switch
- Low Power Drain
- Long Power Cord

Add a cool breeze to your desk with the USB Powered Desk Fan. Plug this compact 4" fan into any powered USB port, flip the switch and enjoy the pleasant steady breeze.

The USB fan's cradle base makes it easy to position the fan for maximum cooling and the long cord makes it a snap to connect to your computer.

USE INSTRUCTIONS:

Uncoil wire attached to fan and plug it directly to any available powered USB port on your computer. This fan can also be plugged directly into a USB hub attached to a computer.

Fan can be plugged directly into a wall receptacle with the included A.C. Adapter. Simply insert USB plug into A.C. adapter and plug into any 120V A.C. / 60Hz. household receptacle.

Turn fan ON/OFF using rocker switch located on the back of the fan.

LAPTOP COMPUTER USERS NOTE:

When plugged into your laptop USB port, this USB fan gets its power from the computer laptop. To avoid laptop battery drain, plug laptop computer into a receptacle while using this fan.

IMPORTANT INSTRUCTIONS:
Save These Instructions

As with all electrical devices, basic safety precautions should always be followed to reduce the risk of electric shock, fire, or injury to persons, including the following precautions:

- Read all the instructions before using this fan.
- Use this fan only as described in this manual. Any other use not recommended by the manufacturer may cause electrical shock, fire or injury to persons.
- Do not operate the fan with a damaged power cord or after the fan malfunctions or has been dropped in any manner.
- Do not use fan unattended. This appliance is not intended for use by persons (included children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not place the fan on a small, unlevel, uneven or any surface which might allow fan to tip or fall.
- For proper operation, fan should be placed on a smooth, non-combustible surface.
- Always unplug fan when not in use.
- Do not operate the fan with blade guards or any safety device removed.
- Do not run power cord under carpeting. Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic area where it will not be tripped over.
- Do not insert or allow any object to enter any openings on the fan. Doing so may cause electric shock and/or fire hazard.

Fan's USB Plug connects to included AC Adapter or any Powered USB Port

WARNING: SHOCK HAZARD

Use your fan only in dry environments. This fan is not intended for use in a bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water. Never locate fan where it may fall into a bathtub or other water receptacle. Do not use in damp environments such as flooded basements.

WARNING: FIRE HAZARD

Fans have arcing or sparking parts inside. Do not use near combustible materials or flammable gases or sources of heat. DO NOT USE in areas where gasoline, paint or flammable materials are used or stored. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock, fire, or damage the fan.

CARE AND MAINTENANCE:

CLEANING: CAUTION-Before cleaning the fan be sure to disconnect power cord from the plug. Unscrew and remove front grill only. Clean the grill and fan blade surface with a clean damp cloth. Do not use harsh chemical or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN WATER. Replace front grill before fan use. Allow fan to dry completely before use. Periodic grill cleaning with a vacuum will prevent dust build up. The motor does not require any interior maintenance, cleaning or lubrication.

REPAIR: DO NOT OPERATE THE FAN WITHOUT THE GRILL IN PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY.

STORAGE: Keep original package for storage of the fan. Coil and tie the power cord to avoid damage during storage.